

Keep Right USA

Thank You for your purchase!

Please call customer service at (951)905-8244 if there is a problem with your order or if you have any questions.

Transfer Decal Installation

Do Not apply decal in direct sunlight.

Apply decal in temperatures between 60 and 80 degrees Fahrenheit.

Inspect decal for damage or defects prior to installation.

Required Items: Installation squeegee, masking tape or marking pencil, glass cleaner, paper towels, razor blade, straight-razor (scraper), measuring tape or ruler, spray bottle (water with 2 drops of dish soap).

1. Clean windshield thoroughly with 409 or like cleaner. Use a straight razor to remove any build-up.
2. Clean windshield with glass cleaner.
3. Measure and mark where the bottom edge should be. Measure 5", or more if desired, from top center of windshield. Using a marking pencil or tape, mark the two sides of the visor strip equally.
4. Remove backing from decal.
5. Spray decal and windshield thoroughly with water and soap solution.
6. Place decal in position. Another person is recommended for this.
7. Squeegee decal from center outwards to remove excess water. Thoroughly squeegee edges from center to edge. Use wet paper towel wrapped over squeegee so you do not scratch decal.
- 8. Cut decal along molding with razorblade. Cut from center outward. Take your time! Do not cut molding.**
9. Carefully squeegee edges again.
10. Allow decal to dry for at least 2 hours, apply wax or rain-x to decal and windshield. This will keep the wipers from damaging the strip during normal use.

Additional information regarding visor strip installation can be found online.

www.KeepRightUSA.com